

TECHNOLOGY
REFERENCE
GUIDE



www.myhonda.ca

31T2AR00
00X31-T2A-R000

2013 Honda Accord Sedan Technology Reference Guide
©2012 Honda Canada Inc. — All Rights Reserved

Printed in U.S.A.



2013 Accord Sedan

TECHNOLOGY REFERENCE GUIDE


The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features. This guide covers the Accord Sedan.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual or Navigation Manual.

As with the Owner's Manual, this guide covers all trim levels of the Accord Sedan. Therefore, you may find descriptions of equipment and features that are not on your particular vehicle.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design obligation whatsoever.

Smart Entry with Push Button Start.....	2
Auto Door Locks	4
Instrument Panel Indicators	6
Multi-Information Display (MID)	8
Color Information Display.....	10
Using the Touchscreen.....	11
Tire Pressure Monitoring System (TPMS)	12
Eco Assist™.....	13
Driving Position Memory System (DPMS).....	14
One-Touch Turn Signal.....	14
Rearview Camera (LX, Sport)	15
Multi-View Rear Camera (EX-L, Touring).....	16
LaneWatch™ (EX-L, Touring).....	18
Lane Departure Warning (LDW) (EX-L, Touring)	19
Forward Collision Warning (FCW) (EX-L, Touring)	20



Voice Recognition.....	22
Navigation (Touring)	26
Bluetooth® HandsFreeLink® (HFL).....	28
SMS Text Messaging and E-Mail	33
Bluetooth® Audio	35
iPod® or USB Flash Drive	36
HDD Audio	37
Song By Voice.....	38
HondaLink featuring Aha™ (EX-L, Touring)	39
HomeLink®	40
Settings for Your Vehicle	41
My Honda.....	42
Safety Reminder	43
Fuel Recommendation.....	43
Floor mat information	43

SMART ENTRY WITH PUSH BUTTON START

Unlocking the Doors




Grab either one of the front door handles.



Locking the Doors



Press the door lock button on either front door handle.



Opening the Trunk



Press the trunk release button under the trunk handle.



Operate certain functions of your vehicle by simply having the remote within operating range.

Engine Start/Stop Button

Accessory or On Mode

Operate audio or other electrical features without turning the engine on.



Press the ENGINE START/STOP button once (without pressing the brake pedal). **Press** it again for ON mode.




Starting the Engine



Press and hold the brake pedal, then **press** the ENGINE START/STOP button.



Turning the Vehicle Off



Shift to Park, then **press** the ENGINE START/STOP button.



Note: If you press the button and the shift lever is not in Park, the vehicle goes into Accessory mode.

AUTO DOOR LOCKS

Door Locks



Default Lock Setting

The doors are preset to lock when your vehicle reaches about 16 km/h.



Default Unlock Setting

All doors are set to unlock when the driver's door is opened.



Program how and when the vehicle doors automatically lock and unlock.

Changing the Door Lock Settings


Below is an example of how to change the auto door unlock setting*. Make sure the vehicle is in ON mode. See your Owner's Manual for other setting options.

Use the interface dial to make and enter selections.

1. Press SETTINGS.




4. Select Auto Door Unlock.



2. Select Vehicle Settings.



5. Select from the options.



3. Move the interface dial to the right to Door/Window Setup.



6. Press BACK to exit the menu.



Note: The driver's and front passenger's door can be opened by pulling the inner front door handle, regardless of the setting. Changing the setting to "All Doors" is useful for rear passengers.

*You can also change vehicle settings using the multi-information display.














INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and orange indicators are most critical. Blue and yellow indicators are used for general information. See your Owner's Manual for more information.



Malfunction Indicators





If an indicator remains on, there may be a problem; see your dealer

 Charging system	 ABS (anti-lock brake system)
 Low brake fluid	 Malfunction lamp (check engine light)
 Low oil pressure	 TPMS (tire pressure monitoring system)
 SRS (supplemental restraint system)	 VSA [®] (vehicle stability assist)
 EPS (electric power steering)	 Smart Entry System
 FCW (forward collision warning system)	 Brake system
 LDW (lane departure warning system)	










 Low fuel: Refill	 Low tire pressure: Add air
 FCW (blinks): Brake	 System message indicator: Check MID
 LDW (blinks): Stay in your lane	

Condition Indicators

Action is needed by driver

 Parking brake on: Release	 Seat belt reminder: Fasten seat belt(s)
 Door/Trunk open: Close door(s) / trunk	 Immobilizer (blinks): Use correct key


On/Off Indicators

 PASSENGER AIRBAG OFF (next to display screen)	 Fog lights on
 VSA OFF	 Headlights on
 ECON Mode on	 Turn signals/hazards on
 CRUISE MAIN on	 High beams on
 CRUISE CONTROL on	

MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

Accessing the Information Display




When you start the engine, the information display shows your last active selection from the previous drive cycle.



To toggle between the different displays:


- Press either info button (▲/▼) for the main displays.
- Press SEL/RESET for the lower displays.

Main Displays



*You can also change vehicle settings using the SETTINGS button on the center panel.

Lower Displays




COLOR INFORMATION DISPLAY

Choose what to display in the center screen.

Changing the Display




Press the Display button to change the main displays.



Display Options

Audio
Shows current audio information.



Phone
Shows phone screen.



Navigation
Shows map or navigation information.



Info
Shows information screen and options.



USING THE TOUCHSCREEN

Interactive touchscreen display includes audio and *Bluetooth*® HandsFreeLink® functionality.

Audio Options

Source: Select audio sources.

Preset: Select preset stations or channels.



Skip/Seek: Change stations, channels, tracks, etc.

More: Select menu options and sound settings.

FM screen shown

Bluetooth® HandsFreeLink® Options*

When you enter the Dial screen from the Phone Menu, you can use the touchscreen to enter the number.



When you enter the Phonebook screen from the Phone Menu, you can use the touchscreen to search for names.




* Manual operation is inoperable while the vehicle is moving.

Sound/Screen Options

Select More from the main screen.



Select Sound Settings to adjust the audio system.



Select Screen Settings to adjust various screen features.

TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.

What to Do

1. **Visually inspect** the tires for damage.
2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.
3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



TPMS Calibration

Any time you inflate, change, or rotate one or more of your tires, you need to recalibrate the system.

1. **Press** SETTINGS.




2. **Select** Vehicle Settings.



3. **Select** TPMS Calibration.



4. **Select** Calibrate.



5. The low tire pressure indicator blinks and calibration begins.



ECO ASSIST™

When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to maximize fuel efficiency.

ECON Button

1. **Press** **ECON** to turn the system on.



2. The **ECON** mode indicator comes on.




3. **Press** **ECON** again to turn the system off.



Ambient Meter

Indicates instant fuel efficiency using color-coded bars.




DRIVING POSITION MEMORY SYSTEM (DPMS)

Store driver's seat positions into memory for each corresponding keyless remote (1 or 2), which are recalled when you unlock the driver's door with the remote and enter the vehicle.

How It Works

1. **Turn on** the vehicle. Make sure the shift lever is in Park (P).



2. **Adjust** your preferred seat settings.



Note: Stored positions can also be recalled by pressing memory buttons (1 or 2) on the door.

3. **Press SET.** You will hear a beep.



4. **Press** the memory button corresponding to the remote (1 or 2) you are using. You will hear two beeps.



REARVIEW CAMERA (LX, SPORT)

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display, along with helpful parking guidelines.
- The display turns off when you shift out of Reverse.



Camera Settings


Turn the guidelines on or off.

Use the selector knob to make and enter selections.

1. **Press SETTINGS.**



4. **Select** one of the options.




2. **Select** Camera Settings.



Fixed Guidelines: Guidelines appear when you shift into Reverse. **Select** On or Off.

Dynamic Guidelines: Guidelines move as you turn the steering wheel. **Select** On or Off.

3. **Select** Rear Camera.



5. **Press** BACK to exit the menu.

ONE-TOUCH TURN SIGNAL

Use this quick and convenient method to signal a lane change.

How It Works

- Lightly push the turn signal lever up or down for a three-blink sequence.
- For a continuous signal, push the lever up or down until it locks into place.



MULTI-VIEW REAR CAMERA (EX-L, Touring)

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display, along with helpful parking guidelines.
- The display turns off when you shift out of Reverse.



Switching Views

There are three rearview modes: wide, normal, and top down. **Press** the interface dial to toggle between views.



Wide (default)



Normal



Top down



Camera Settings


Turn the guidelines on or off.

Use the interface dial to make and enter selections.

1. **Press** SETTINGS.



4. **Select** one of the options.



2. **Select** Camera Settings.



Fixed Guidelines: Guidelines appear when you shift into Reverse. **Select** On or Off.

Dynamic Guidelines: Guidelines move as you turn the steering wheel. **Select** On or Off.

3. **Select** Rear Camera.



5. **Press** BACK to exit the menu.



LANEWATCH™ (EX-L, TOURING)


Helps you check your right blind spots when you make a right lane change.

How It Works

When the right turn signal is activated, a camera located in the passenger side door mirror shows the right rear area outside your vehicle on the display.



Visibility Area



LaneWatch Display

Press the LaneWatch button on the turn signal switch to view a constant real-time display. **Press** it again to turn the display off. The display still appears when the right turn signal is activated.



See your Owner's Manual for information on adjusting LaneWatch settings.

LANE DEPARTURE WARNING (LDW) (EX-L, TOURING)


Alerts you if your vehicle begins to move out of a detected lane without the turn signal activated.

How It Works

A camera mounted in the center of the upper windshield determines if your vehicle begins to move away from the center of a detected lane.




If you cross a lane line without using your turn signal, the LDW indicator flashes, a message appears on the MID, and a beep sounds.



LDW may not activate under certain conditions. See your Owner's Manual for more information.

Turning LDW On or Off

Press the LDW button to turn the system on or off.



FORWARD COLLISION WARNING (FCW) (EX-L, TOURING)

Alerts you to the possibility of a front-end collision.

How It Works

If the radar sensor in the front grille detects a vehicle in front of you when your vehicle speed is 16 km/h or higher--and it determines there is a likelihood of a frontal collision--the system provides you with the following visual and audible warnings:



EX-L shown

With the FCW Distance set to Short:

- the heads-up light near the windshield flashes continuously
- the FCW indicator flashes continuously
- a beep sounds continuously until you take preventive action



With the FCW Distance set to Normal or Long:

- the heads-up light near the windshield and FCW indicator flash twice
- if you do not take action to prevent a collision and the distance to the other vehicle becomes sufficiently close, BRAKE flashes on the MID, the FCW indicator and heads-up light flash, and a beep sounds continuously until you take preventive action



FCW may not activate under certain conditions. See your Owner's Manual for more information.

Customizing FCW

Use the interface dial to make and enter selections.


1. Press SETTINGS.



2. Select Vehicle Settings.



3. Move the interface dial to the right to Driver Assist Style.




4. Select Forward Collision Warning Distance.



5. Select one of the options.

- Long:* early warning timing
Normal: standard warning timing
Short: late warning timing
Off: Turn the system off



6. Press BACK to exit the menu.



VOICE RECOGNITION

How It Works

Control four different systems with the steering wheel buttons and the ceiling microphone.

To reduce the likelihood of driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.



Pick-Up button: Answer an incoming call or go to a phone-specific voice portal screen.

Hang-Up/Back button: End a call, decline an incoming call, or cancel an operation.

Talk button: Give phone, navigation, audio, or climate control commands.





Voice Command Tips

- To hear a list of available commands at any time, press and release the Talk button, then say “Help.”
- When using the Talk button, wait for a beep, then give a command.
- When the Talk button is pressed, all available voice commands are highlighted in yellow.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.


To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, audio, and climate control. For a full list of commands, say “Information” and “Voice Command Help.”

Voice Command Portal

When you press the Talk button from any of the main screens (NAV, PHONE, INFO, AUDIO), the voice portal screen appears and the system gives you examples of voice commands that can be used. For more examples, see [page 24](#).



Press the Talk button again, and the system waits for you to say a command.



The system recognizes your command.



The system confirms the command.

Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you give a command.

General Commands

(Accepted on most screens to change displays)


- Display map
- Display menu
- Display phone
- Information
- Display audio screen
- What time is it?



Find Place Commands

(Accepted on Map screen)


- Find nearest:
 - ATM
 - gas station
 - Mexican restaurant
 - post office
 - Honda dealer
 - airport
 - hospital
 - bank



Navigation Commands

(Accepted on Map screen)


- How long/far to the destination?
- Display destination map
- Display entire route



Display Commands

(Accepted on Map screen)

- Display (or hide):
 - ATM
 - gas station
 - restaurant
 - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location




Press and release the Talk button before you give a command.

Audio Commands

(Accepted on most screens)


- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- DISC play
- DISC play track #
- DISC skip forward/back
- iPod/USB/HDD play



Phone Commands

(Accepted on most screens)

- Call by name
- Call by number



Climate Control Commands

(Accepted on most screens)

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 18-28)
- Temperature max hot/cold



Help Commands

(Accepted on most screens)

- Voice help (list of all available commands by category)



NAVIGATION (TOURING)

Entering a Destination Using Voice Commands

Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you give a command.



1. **Say** "Address."
4. **Say** the entire street address number. For example, "1-2-3-4." If necessary, **say** "OK" to proceed.



2. **Say** "Street," then spell the street name one letter at a time. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).
5. If the street address is in more than one city, a list of city names appears. **Say** the number next to the city you want to select.



3. A list of street names appears. **Say** the number next to the street you want.
6. **Say** "Set as destination" to set the route.



NOTE: It is recommended that you enter your destination before driving or when the vehicle is stopped.


Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

Using the "Find Nearest" Command


Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you give a command.


1. From the map screen, **say** "Find nearest ATM."
3. **Say** the number next to the destination you want to select.



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
4. **Say** "Set as destination" to set the route.



Map Screen Legend



BLUETOOTH® HANDSFREELINK®

Make and receive phone calls through your vehicle's audio system. Visit handsfreelink.ca to check if your phone is Bluetooth-compatible.


To reduce the likelihood of driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. Stop or pull over to perform the function.

Using HFL

Pick-Up button: Answer an incoming call or go to a phone-specific voice portal screen.

Hang-Up/Back button: End a call, decline an incoming call, or cancel an operation.

Talk button: Make a call using a stored voice tag, phonebook name, or phone number.




Use these buttons to navigate through the HFL menus.

PHONE button: Go to the phone screen.

BACK button: Cancel an operation or return to the previous screen.

SETTINGS button: Go to Phone Settings to pair a phone and set up text/mail options.



Interface Dial: Rotate to scroll through selections and press to make a selection.

MENU button: From the Phone screen, access Speed Dial, Redial, Call History, Phonebook, Dial, and Text/Mail options.

Pairing Your Phone

Pair your phone to begin using hands-free phone and related audio functions. The vehicle must be stopped to pair the phone.

Use the interface dial to make and enter selections.

1. Press SETTINGS.



2. Select Phone Settings.



3. Select Bluetooth Device List (if no phone has been paired) or Connect Phone (if another phone has been paired).




4. Select Add Bluetooth Device.



5. Make sure your phone is in discovery mode.




6. HFL searches for your phone. Select your phone when it appears on the list.




If your phone does not appear:

Select Phone Not Found and search for HandsFreeLink from your phone.

7. HFL gives you a six-digit code. Compare it to the code that appears on your phone. If it is the same, connect to HFL from your phone.



8. The system asks if you want to enable Phone Synchronization. Select On.



Dialing a Number

Enter a 10-digit phone number to call.

Using the Menu*

Use the interface dial to make and enter selections.

1. Press PHONE.



3. Select Dial.



2. Press MENU.



4. From the navigation screen or the touchscreen, enter the phone number. Select the green Dial icon to call.



*This feature is inoperable when the vehicle is moving.

Using Voice Commands

Press and release the TALK button to say a command.

1. Say "Dial by number."



3. Say "Dial." The system begins to dial.



2. Say the phone number.



Using Speed Dial

Store 20 speed dial entries for quick calling.

Using the Menu

Use the interface dial to make and enter selections.

1. Press PHONE.



3. Select the entry to call.



2. From the Speed Dial tab, scroll the list of speed dial entries.



Using Voice Commands

When a speed dial entry is stored with a voice tag, you can make a call using voice commands at any time. See your Owner's Manual for more information.

Press and release the TALK button to say a command.

Say "Call" and the stored voice tag name. The system begins to dial.



You can also say the name and type of any phone number stored in your phonebook. For example, say "Call by name" followed by "John Smith mobile."

Note: Phone synchronization must be on for the "Call by name" feature to work.

Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system. This feature is inoperable when the vehicle is moving.

Use the interface dial to make and enter selections.

1. Press PHONE.




3. Select Phonebook.



2. Press MENU.




4. Scroll through the list to find the name and number you want to call, and select it to call.



Receiving a Call

When you receive an incoming call, you hear a notification and see the following pop-up message:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.




SMS TEXT MESSAGING AND E-MAIL

Receive and send text messages and e-mails from your paired and linked phone using Bluetooth® HandsFreeLink®. Visit handsfreelink.ca to see if this feature is compatible on your phone. Standard message rates apply. This feature is limited while the vehicle is moving.


Receiving Messages

Use the interface dial to make and enter selections.

1. A notification appears on the display. **Select** Read to open the message.




2. The message is displayed, and the system reads it aloud.




Replying to Messages

Use the interface dial to make and enter selections.


1. With the message open, **move** the interface dial down to select Reply.



3. **Select** Send to send the message.




2. **Select** one of the six available reply messages.



Calling the Sender

Use the interface dial to make and enter selections.



1. With the message open, **move** the interface dial down to select Call.
2. HFL begins dialing the number.



Displaying Messages

Use the interface dial to make and enter selections.

1. Press PHONE.
2. Press MENU.
3. Select Text/Email. The 20 most recent messages are displayed.
4. Select Inbox or the desired folder.
5. Select a message to open it and hear it read aloud.




Note: Notifications and operation for SMS Text and E-mail are separate. Choose your desired account in the Phone Settings menu.

BLUETOOTH® AUDIO

Stream audio from your compatible phone through your vehicle's audio system. Visit handsfreelink.ca to check if this feature is available on your phone.

Playing Bluetooth Audio


1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see page 29).
2. Press SOURCE.
3. Press the Bluetooth icon.
4. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.
5. Press (⏮) or (⏸) on the screen or (⏮) or (⏸) on the steering wheel to change tracks.



3. Press the Bluetooth icon.



4. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.



Notes:


- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function and remote audio controls may not be supported on all phones.

iPod® OR USB FLASH DRIVE


Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Connecting Devices and Playing Audio Files


1. **Open** the USB port in the front console. **Connect** the dock connector or flash drive.
5. **Press** (▶▶) or (◀◀) on the screen or (▶) or (◀) on the steering wheel to change tracks.




2. **Press** SOURCE.



3. **Press** the iPod or USB icon.



4. **Press** the album or folder bar to change albums or folders.



iPod is a registered trademark of Apple Computer, Inc., registered in Canada and other countries. iPod not included.

HARD DISC DRIVE (HDD) AUDIO

Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

Playing HDD Audio


1. **Press** SOURCE.



2. **Press** the HDD icon.





3. **Press** (▶▶) or (◀◀) on the screen or (▶) or (◀) on the steering wheel to change tracks.




Searching for Music

Use the interface dial to make and enter selections.

1. From the audio screen, **move** the interface dial to the left to go to the HDD search screen.
3. **Select** a track and **press** ENTER to begin playing.



2. **Select** one of the categories.



SONG BY VOICE™ (SBV)

Play songs from your iPod and HDD from most navigation/audio screens by using simple voice commands.

Playing Audio Files Using Voice Commands


Using the "Play" Command

Press and release the Talk button before you give a command.


1. Say "Music search."



2. Say "Play" and a search option. For example, say "Play artist XYZ."



3. The system plays the first song by the artist and returns to your original screen.




Using the "List" Command

Press and release the Talk button before you give a command.


1. Say "Music search."




2. Say "List" and a search option. For example, say "List artist XYZ."



3. A list of tracks by the selected artist displays. Say the number of your selection. For example, say "One."



4. The system plays the first song by the artist and returns to your original screen.



HondaLink featuring Aha™ (EX-L, TOURING)

Access music and entertainment programming, location-based services, and social media sites through your vehicle's audio system. Download the HondaLink app to your phone prior to using this feature at owners.honda.com/apps. Visit handsfreelink.ca to check if this feature is available on your phone. Standard data rates apply.

Playing Aha

1. For Bluetooth connection: Make sure your phone is paired to Bluetooth® HandsFreeLink® (see page 29) and the screen is on and unlocked.
4. From the screen, select items such as Like/Dislike and Play/Pause.

For USB connection: Connect the dock connector to the USB port.



2. Press SOURCE.



3. Press the Aha icon on the second screen and streaming begins.



Press Stations to select from 16 favorite stations.

Press MENU to access the complete station list.



Notes:

- You can select Bluetooth or USB priority connection in the Audio Settings menu (see page 41). This establishes what kind of connection will happen every time you turn your vehicle on.
- iPhone can connect via Bluetooth or USB; Android can connect via Bluetooth only.
- If you cannot operate Aha through the audio system, it may be streaming through Bluetooth® Audio. Make sure the Aha source on your audio system is selected.

HOMELINK®

The HomeLink Universal Transceiver can be programmed to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

Training a Button



1 Position the remote transmitter you wish to link 2-5 cms from the HomeLink button you want to program.

2 Press and hold the desired HomeLink button and the button on the remote transmitter.
Does the HomeLink indicator (LED) blink at a faster rate after about 10 seconds?

NO

YES

a Press and hold the button on the remote and the HomeLink button at the same time. Then, while continuing to hold the HomeLink button, **press and release** the button on the remote every 2 seconds.
Does the LED blink at a faster rate within 20 seconds?

NO

YES

3 Press and hold the programmed HomeLink button for about a second.
Does the device (garage door opener) work?

NO

YES

4 Press and hold the HomeLink button again.

Training complete

HomeLink indicator flashes for 2 seconds, then remains on. HomeLink LED remains on.

a The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g., garage door opener).

b Within 30 seconds, **press and hold** the programmed HomeLink button for 2 seconds.

5 Press the programmed HomeLink button again; the remote-controlled device should operate.

If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit www.homelink.com.

SETTINGS FOR YOUR VEHICLE

Change different settings for many features in your vehicle. See your Owner's Manual for detailed information on settings and options.

Adjusting Vehicle Settings



Press **SETTINGS** to select the settings menu. Use the interface dial to make and enter selections.

Choose from the available options:



Navi Settings

Change various settings for navigation system routing.

Camera Settings

Change camera modes.

Vehicle Settings

TPMS calibration, meter setup, door setup, and more.

System Settings

Adjust the display, system language, and more.

Phone Settings

Pair a phone, change call and text/e-mail options, and more.

Info Settings

Import wallpaper and select clock type.

Audio Settings

Change sound options and various settings for audio modes.

MY HONDA

My Honda allows you to explore features and technologies specific to your vehicle, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at www.myhonda.ca to assure that you continue to enjoy the experience of owning a Honda.

Fransais

HONDA
The Power of Dreams

Member Sign In

Email

Remember My Email

Password

[Forgot your password?](#)

Not a Member?

Member Benefits

Register now to become an exclusive member. It's fast, it's easy and it's free! To get started you will only need your:

- Vehicle Identification Number (VIN)
- Last Name
- Postal Code

Once a member, your benefits will include:

- Accessing your vehicle specific information from a convenient, single source location
- 24-hour / 7 day a week access
- Valuable warranty, maintenance and campaign information
- Current Honda Canada Finance and Honda Plus extended warranty account information
- Latest Honda product news and event information

and much more...

[View Demo](#)

SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

FUEL RECOMMENDATIONS

- **OCTANE:**Your Honda is designed to run on unleaded gasoline with a pump octane number of 87 or higher.
- **FUEL QUALITY, TOP TIER:** Honda recommends the use of TOP TIER Detergent Gasoline (TTDG). TTDG is a strict performance standard for fuel quality that specifies appropriate detergency and prohibits deposit-forming metallic additives. Deposits degrade the performance and reliability of your vehicle, and may contribute to increased fuel consumption and tailpipe emissions. Qualifying Retailers guarantee that all gasoline grades meet or exceed the standard at each retail location. TTDG Retailers may be found at www.toptiergas.com/retailers.html or for information visit www.honda.ca.
- **NO MMT:** Some gasoline in North America contains MMT, a manganese based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system.

FLOOR MAT INFORMATION

Following these guidelines will help ensure your safety by preventing the floor mats from interfering with accelerator, brake, or clutch (if applicable) pedal operation. Your vehicle's original driver's floor mat is anchored to the floor to ensure it does not move and cause interference with pedal operation. When you remove your mats to clean them ensure the driver's floor mat is installed and properly secured to the vehicle with the floor anchors before driving.

If you decide to install different floor mats, such as all-weather floor mats, ensure the driver's floor mat is made to fit your vehicle specifically. The driver's floor mat must be anchored to the floor in the same manner as your original mats. Furthermore, do not place newspapers or other absorbent materials on the floor area as this can lift the mat or freeze overnight and interfere with pedal operation. Finally, ensure that there is only one driver's floor mat installed as original anchors are designed to secure only one mat. An unsecured floor mat may interfere with pedal operation, increasing the risk of a collision.